

# Pyxis<sup>®</sup>

## CLOUD-BASED RADAR LEVEL SENSOR



### POWERING ON THE UNIT

Tap the provided magnetic wand to the top of the sensor, a light will indicate successful start-up!



### CONFIGURATION GUIDE



Scan the QR Code and fill out our Configuration Form to start monitoring for container level anytime, anywhere. Once the form is submitted, our team will remotely configure your sensor & send you login information to our Cloud Data Management System!



# INSTALLATION



Thread the provided 2inch MNPT adapter into your container and simply insert the Radar Level Sensor into the adapter opening.

1



2



# CLOUD LOGIN



Once you have powered on the device & completed the Configuration Form, our team will provide login information for you to access your account at **[www.pyxis-cloud.com](http://www.pyxis-cloud.com)**

## CONTACT US.

+1 (866) 203-8397

service@pyxis-lab.com

www.pyxis-lab.com

21242 Spell Circle, Tomball TX 77375